



- DRAINAGE FITTINGS MUST BE USED FOR ALL PORTIONS OF THE VENT LOCATED BELOW THE FLOOR
- HORIZONTAL DRAIN AND VENT PIPING MUST BE SLOPED AT A MINIMUM 1/4-INCH PER FOOT