

- POT SINKS, SCULLERY SINKS, COMMERCIAL KITCHEN SINKS, BEVERAGE SERVICE SINKS, DISHWASHING SINKS, AND SILVERWARE SINKS MUST BE DIRECTLY CONNECTED TO THE DRAINAGE SYSTEM. A FLOOR DRAIN WITHOUT BACKWATER VALVE MUST BE PLACED ADJACENT TO THE FIXTURE. THE FLOOR DRAIN MUST BE INSTALLED ON THE INDIVIDUAL DRAINAGE BRANCH OF THE SINK THAT IS BEING PROTECTED.
- TELL-TALE FLOOR DRAIN (TTFD) = FLOOR DRAIN WITHOUT BACKWATER VALVE

m	DEPARTMENT OF LABOR AND INDUSTRY	Tell-Tale Drains on Commercial Sinks		(M.R. Chapter 4714, Section 704.3)	3/22
		Phone: (651) 284-5063	dli.mn.gov/business/plumbing-contractors/alternates-checklists-and-other-information		